

### Parts List

① FEMALE-PT Top Cover	Quantity: 1
② FEMALE-PT Bottom Cover	Quantity: 1
③ PowerTap <sup>®</sup> Receptacle	Quantity: 1
④ Female PowerTap Pins	Quantity: 2
⑤ Screw	Quantity: 1
⑥ Nut	Quantity: 1

### Instructions for Attaching to a Cable

1. Solder the wire/cable to the Female PowerTap Pins④. Note polarity of connector.
2. Insert the Female PowerTap Pins④ into the PowerTap Receptacle③.
3. Insert the PowerTap Receptacle③, with Female PowerTap Pins④ installed, into the FEMALE-PT Bottom Cover②.
4. Install FEMALE-PT Top Cover① onto the FEMALE-PT Bottom Cover②.
5. Place the Nut⑥ into the FEMALE-PT Top Cover②.
6. Insert the Screw⑤ through the FEMALE-PT Bottom Cover② and tighten. Do not overtighten.

