

CINE VCLX with ON/OFF Switch



Anton/Bauer Main Number
203-929-1100

www.antonbauer.com

Our CINE VCLX series batteries have been updated recently with an ON/OFF switch installed onto the top of the battery. We have since upgraded the switch based on your feedback.

The original switch is a raised button that could have the potential to cut power if hit during a shoot.

The new switch is a depressed style to eliminate any unintentional shut off.

Please contact Customer Support Group if you would like to get an updated switch assembly and installation information.

Note:

There is a slight modification to the CINE VCLX battery to mount the new switch. Customer Support has instructions and a small quantity of tools available for this modification if you wish to perform it yourself or Battery can be returned to Customer support for upgrade.

Customer Support Group can be contacted in the following manner:

USA:
Email: support@antonbauer.com
Phone: 203-925-4991 or
800-541-1667
Fax: 203-925-5203

EUROPE:
Email: rploeg@antonbauer.com
Phone: +31-45-5639220
Fax: 203-925-5203

ASIA:
Email: adamkoh@starhub.net.sg
Phone: +65-6285-7452

Latest Charger Revisions	
Model	Rev.
QUAD 2702	5.1
DUAL 2722	2.9
TWIN	18.0
Tandem 70	11.0
T2	2.9
TWQ	18.0
CINE VCLX Charger	3.0
Cine VCLX/2 Charger	1.0