


Proper Connections Using the ElipZ[®] 10K Battery System




To ensure proper connection of the ElipZ camera adaptor to the ElipZ battery:

- Make sure the adaptor is not installed into the camera.
- Ensure the proper alignment is made before trying to install the connector. (See above picture.)
- Once alignment is correct, push in the connector to create a solid connection.
- Now install the camera adaptor into the camera.

See below for proper cable handling:

When removing the ElipZ cable from the ElipZ 10K battery always grasp the connector and pull straight out.

Never grasp the cable by the cord!
Improper removal can cause damage to both the battery and cable.



The Customer Support Group can be contacted in the following manner:

USA:

Email: support@antonbauer.com
Phone: 203-925-4991 or
800-541-1667
Fax: 203-925-5203

EUROPE:

Email: rploeg@antonbauer.com
Phone: +31-45-5639220

ASIA:

Email: adamkoh@starhub.net.sg
Phone: +65-6285-7452



Anton/Bauer Main Number
203-929-1100

www.antonbauer.com

Latest Charger Revisions

Model	Rev.
QUAD 2702	5.4
DUAL 2722	3.2
TWIN	20.0
Tandem [®] 70	15.0
T2	3.2
TWQ	20.0
CINE VCLX Charger	3.0
Cine VCLX/2 Charger	1.0