



Gold Mount Battery Bracket Canon (C100, C300, C500)

SKU: 8075-0267

PRODUCT DESCRIPTION

Gold Mount battery plate with C-Series DC connector. Works with Canon C100, C300, and C500. Voltage regulator integrated in the plate provides constant 9V to camera. Two P-Taps on plate provide 12-16V depending on battery connected.

Cable exits the right side of the plate allowing neat looping and insertion into the camera. The 16" cable minimizes cable excess while still being able to reach positions further away from the camera as necessary.

For an adjustable mount system, use the Universal Mounting Plate for rail mounted cameras – MATRIX Cheese Plate

[LEARN MORE ABOUT THE MATRIX CHEESE PLATE](#)

TECHNICAL SPECIFICATIONS

Camera Brand	Canon
Camera Model	C100, C300, C500
Height	85.1 mm 3.35 in
Width	11.92 cm 4.69 in
Depth	12.9 mm 0.51 in
Weight	0.08 kg 0.18 lb
Mount Type	Gold Mount
Compatibility	Specialized

IN THE BOX

- Gold Mount battery plate
- 2x P-Tap ports
- Canon C-Seroes DC connector
- 16" cable