



Gold Mount Battery Bracket Panasonic (GH3, GH4, GH5, GH5S, G9)

SKU: 8075-0319

PRODUCT DESCRIPTION

Gold Mount battery plate with a Panasonic GH3 / GH4 / GH5 DC connector and two P-Taps to power camera accessories. An integrated regulator in the plate provides the correct voltage to the camera.

Cable exits the right side of the plate allowing neat looping and insertion into the camera. The 16" cable length minimizes cable excess while still being able to reach positions further away from the camera as necessary.

For an adjustable mount system, use the Universal Mounting Plate for rail mounted cameras – MATRIX Cheese Plate

[LEARN MORE ABOUT THE MATRIX CHEESE PLATE](#)

TECHNICAL SPECIFICATIONS

Camera Brand	Panasonic
Camera Model	G9, GH3, GH4, GH5, GH5S
Height	85.1 mm 3.35 in
Width	11.92 cm 4.69 in
Depth	12.9 mm 0.51 in
Weight	0.098 kg 0.22 lb
Mount Type	Gold Mount
Compatibility	Specialized

IN THE BOX

Gold Mount battery plate
2x P-Tap ports
Dummy Panasonic battery
16" cable