



Pro Gold Mount Battery Bracket Canon (C200, C200B, C300mkII)

SKU: 8075-0275



PRODUCT DESCRIPTION

Anton/Bauer Pro Gold Mount (Canon C200, C200B, C300mkII) with a rugged aluminum body for durability and secure battery mounting and a Canon C300mkII, C200, C200B LEMO compatible connector. Features 3x P-Taps for accessory power at battery voltage (12-16V), a digital fuse with reset button, rear cover plate, and captive mounting screws.

Should the user exceed the set current for accessories, only the accessory outputs are disabled leaving the camera running normally. Once the current load has been reduced by either removing accessories or reconfiguring, the reset button can be pressed to enable accessory power again.

12" cable exits the right side of the plate allowing easy insertion into the camera.

For an adjustable mount system, use the Universal Mounting Plate for rail mounted cameras – MATRIX Cheese Plate

[LEARN MORE ABOUT THE MATRIX CHEESE PLATE](#)

TECHNICAL SPECIFICATIONS

Camera Brand	Canon
Camera Model	C200, C200B, C300mkII
Height	76.2 mm 3 in
Width	14.61 cm 5.75 in
Depth	19.1 mm 0.75 in
Weight	0.186 kg 0.41 lb
Mount Type	Gold Mount
Compatibility	Specialized

IN THE BOX

- Gold Mount battery plate
- 3x P-Tap ports
- Canon C-Series LEMO compatible connector
- 12" cable
- Digital fuse with reset button