



Pro V-Mount Battery Bracket Sony (FS7, FS5) & Panasonic (EVA1)

SKU: 8075-0282



PRODUCT DESCRIPTION

Pro V-Mount (Sony FS7, FS5, Panasonic EVA1) power plate with a rugged aluminum body for durability and secure battery mounting and a DC connector compatible with Sony PXW-FS7, FS7mkII, FS5, and Panasonic EVA1 cameras. Features 3x P-Taps for accessory power at battery voltage (12-16V), a digital fuse with reset button, rear cover plate, and captive mounting screws.

Should the user exceed the set current for accessories, only the accessory outputs are disabled leaving the camera running normally. Once the current load has been reduced by either removing accessories or reconfiguring, the reset button can be pressed to enable accessory power again.

Also works with Sony EX3 cameras.

Cable length: 15 inches (381mm)

For an adjustable mount system, use the Universal Mounting Plate for rail mounted cameras – MATRIX Cheese Plate

[LEARN MORE ABOUT THE MATRIX CHEESE PLATE](#)

TECHNICAL SPECIFICATIONS

Camera Brand	Panasonic, Sony
Camera Model	EVA1, FS5, FS7
Height	83.8 mm 3.3 in
Width	12.07 cm 4.75 in
Depth	20.8 mm 0.82 in
Weight	0.181 kg 0.4 lb
Mount Type	V-Mount
Compatibility	Specialized

IN THE BOX

- Metal body V-Mount plate
- 3x P-Taps
- Digital Fuse with reset button
- 15" cable